



# TOWING SAFETY

FOR YOUR MOBILE DUSTLESS BLASTING® MACHINE

---

## Safety Checklist (BEFORE YOU DRIVE AWAY)

- Trailer is evenly loaded.
- If carrying a pallet of media in the back of the trailer, the water tank should always be filled to evenly distribute weight.
- Toolboxes are latched and secured.
- Compressor canopy is lowered and secured.
- Loose objects are secured down with ratchet straps.
- Fill funnel and accessories are put away.
- Hoses are coiled and secured.



Watch the Video  
Scan here!

## Trailer Hookup Procedures

1. With the winding crank, lower the trailer onto the 2 <sup>5</sup>/<sub>16</sub>" ball hitch until the foot is *just* off the ground.
2. Ensure the hitch is latched, and safety pin behind the collar is installed.
3. On the foot, remove the pin, raise the drop foot, and pin it again at the highest setting.
4. Retract foot the rest of the way with the winding crank.
5. Hook up safety chains, crossing them to make a cradle.
6. Pull emergency brake clip out of its box.
7. Loop the emergency brake clip through the safety chain receiver.
8. Run this wire through the safety pin on the hitch, to prevent slack from dragging on the ground.
9. Plug the brake clip back into its box.
10. Plug in lights and make sure they work.