

ROTAIR D185T4F

PRE-WORK CHECKLIST



The following items should be checked as indicated to maintain the warranty and ensure years of trouble-free service from the machine.

DAILY

- Engine oil level**
Oil must reach the full mark, located on the fifth line up from the end of the dipstick.
- Engine coolant level**
Top off with Green 50/50 Coolant mix. Fill reservoir completely.
- Compressor oil level**
Oil must reach the full mark which is located where "MAX" is on the dipstick.
- Check for leaks in fuel lines, fuel filter seal, and fuel tank cap**
- Check for leaks in oil filter seal, hydraulic lines and fittings, pneumatic blue lines, and clear lines**
- Make sure there is no obstruction of the canopy vents**
Obstruction could include debris in the vents or proximity of the vents to a vehicle or structure.
- Make sure there is no obstruction in the radiator fins**
Obstruction could include blast media or debris preventing air flow through the radiator.

- Check engine air filters (in severe conditions)**
To remove debris, tap out filter media with the large filter opening facing upward on a hard surface. Replace filter element if necessary.
- Check compressor air filters (in severe conditions)**
To remove debris, tap out filter media with the large filter opening facing upward on a hard surface. Replace filter element if necessary.

WEEKLY

- Engine air filter**
Replace filter element if filter element is compromised or cannot be tapped out.
- Compressor air filter**
Replace filter element if filter element is compromised or cannot be tapped out.

MONTHLY

- Inspect battery electrolyte/water level, top off just above the cell plates**
Top off with Distilled water only

Any leaks found (Oil or Fuel) must be repaired before operation.

SUPPORT

ELGi North America
(704) 523-4123

SUPPORT

Dustless Blasting
(281) 869-3421



support.dustlessblasting.com