

ROTAIR D185T4F

# QUICK REFERENCE



NAME	PART #	QTY
<b>50HR/3 Month Service Kit</b>		
Engine fuel filter	ED0021753180-S	1
Engine oil filter	ED0021750010-S	1
Compressor oil	AL-00025	2.4 gal
Compressor oil filter	099-008-S	1
<b>250HR/6 Month (Engine Only)</b>		
Engine fuel filter	ED0021753180-S	1
Engine oil filter	ED0021750010-S	1
<b>500HR/Annual Service Kit</b>		
<b>204-13600052-S</b>		
Engine fuel filter	ED0021753180-S	2
Engine oil filter	ED0021750010-S	2
Outer engine air filter	162-0086-S	1
Inner engine air filter	162-0087-S	1
Compressor oil filter	099-008-S	1
Outer compressor air filter	162-576-S	1
Inner compressor air filter	162-577-S	1
<b>2000HR/Bi-Annual Filters Kit</b>		
<b>204-13600054-S</b>		
Engine fuel filter	191-0950-S	8
Engine oil filter	099-1010-S	8
Outer engine air filter	162-0086-S	4
Inner engine air filter	162-0087-S	4
Compressor oil filter	099-008-S	4
Outer compressor air filter	162-576-S	4
Inner compressor air filter	162-577-S	4
Oil mist separator filter	157-171-S	1
SPARE PARTS	PART #	NOTES
Check valve, 1/8" below regulator	033-001-S	
Check valve, 1/4" on regulator	033-0178-S	Up to ser#C41089
1.4 Bar oil pressure switch	154-033-S	Ser# C41090-C41474
3.5 Bar oil pressure switch	154-025-S	Ser# C41090-C41474
Separator tank temp sensor	103-008-S	
Air end temp sensor	103-0125-S	
Solenoid valve/start valve	160-052-S	From ser# C41475
Solenoid valve/start valve	160-0871-S	Ser# C41090-41474
Safety valve, on separator mount	033-059-S	
Pressure regulator valve assembly	024-0323-F	

